

## FASTENERS

Plastic pin rivets, one piece plastic rivets, stainless steel nails, or a choice of screws can be used with Prime Panels. Select the appropriate fastener for the panel (ie. FRP, wood, foam, fluted polypropylene) and the application (ie. plasterboard, wood studs, steel studs, concrete).

Plastic pin rivets (two piece) are the universal fastener for attaching panels to wood, metal, drywall, foam etc. Use a 1/4" (.250") or "F" (.257") drill bit.



One piece plastic rivets fasten panels to wood. Use a "K" (.281") drill bit.



**NOTE:** For FRP liner panel installation, pre-drill hole 1/8" (.125") larger than the diameter of the rivet to allow for expansion.

Nails fasten panels to wood. A stainless steel ring shank or spiral shank nail is recommended.



Screws attach panels to wood or metal. Choose a stainless or coated screw with the proper head, length, point, diameter, and thread size that best fits the application.