



INSTALLATION MANUAL

GENERAL GUIDE: The information in this IM is intended to serve as a general guide to proper installation with no warranties intended or implied. Prime Panels assumes no responsibility for improper installation. Please call us at 1-800-990-3468 with any installation questions.

SAFETY FIRST: Always wear protective gear when working with fiberglass, metal, wood, etc.



RECEIVING

Make an inspection of the panels. Check for any shipping damage. Any damage must be noted on the Bill of Lading and signed by the shipper. Also, notify Prime Panels immediately of any damage. Do not install unacceptable panels.

STORAGE

Panels should be stored indoors on a flat, dry surface. Avoid fresh concrete and other surfaces that produce moisture. Allow panels to reach the temperature of the installation location for a minimum of 24 hours.

TOOLS

Power saws with carbide tipped blades are recommended for cutting panels. Basic construction tools: measuring tape, hammer, drill, level, caulking gun, etc. will be used for installation.



PREP

For FRP liner or laminated panel installation, the wall surface must be clean and dry. The surface should be flat, smooth, and free of any loose material (ie. paint, plaster, wall paper). For laminated panel installation, the wood or steel studs should be fastened to the floor and ceiling plates.